



- 1) PLACE POSTS IN FLOOR SOCKETS.
- 2) ADJUST END POST HEIGHTS TO EITHER REGULATION MEN'S OR WOMEN'S HEIGHT.
- 3) ATTACH NET ROPE TO POST HOOK AT ONE END AND TO WINCH LEADER STRAP AT OTHER END ENSURING THAT BOTH CABLES ARE OVER PULLEYS.
- 4) TIGHTEN WINCH UNTIL NET HEIGHT AT CENTRE COURT MEETS REGULATION HEIGHT. NOTE: DO NOT TIGHTEN WINCH PAST THIS POINT.
- 5) TIGHTEN NET STRAPS AT EITHER END. (SEE HUCK NET TIGHTENING SYSTEM INSTRUCTION) NOTE: KEEP STRAPS HORIZONTAL AS POSSIBLE.
- 6) ADJUST END OF NET HEIGHT TO TO MEET REGULATION HEIGHT BY ADJUSTING POSITION OF NET STRAPS ON POST.
- 7) IF THERE ARE ROPES ON THE BOTTOM OF THE NET TIE THEM OFF TO THE END POSTS.

<small>UNLESS OTHERWISE SPECIFIED:          3 PLACE DECIMALS +/- .002 TOL.          2 PLACE DECIMALS +/- .010 TOL.          FRACTIONAL DIMS. +/- 1/32 TOL.          ANGULAR DIMS +/- 0 DEG 15' TOL.</small>	<b>Spieth-Anderson International Inc.</b> Forestview Rd., P.O. Box 40 Orillia, Ontario Canada L3V 6H9		
	<b>PART:</b> Volleyball Net Setup Instructions		
<small>COPYRIGHT          SPIETH-ANDERSON INT'L INC.          CONFIDENTIAL: RELEASED AND          ACCEPTED BY THE POSSESSOR ON          CONDITION THAT NO RIGHTS OF          REPRODUCTION OR USE ARE GIVEN          EXCEPT FOR PURPOSES ELSEWHERE          SPECIFIED IN WRITING BY          SPIETH-ANDERSON INT'L INC.          ORILLIA, ONTARIO          CANADA.</small>	<b>DWN:</b> LAW	<b>DATE:</b> 07/11/05	<b>CHK'D:</b>
	<b>SCALE:</b> NTS		<b>DWG No.:</b>